SEAT BMS Function List(Note:For reference only)									
NOTES:	NOTES :								
• This functi	• This function is supported. (Except that the electronic control unit not equipped)								
💥 This functi	on may be suppo	orted, which depends on the actual condition of the							
O This functi	on is not suppo	orted.							
▲ This functi	on is the new t	feature in this version.							
Vehicle	Year	BMS							
Alhambra	2001 - 2021								
Altea	2004 - 2015								
Ateca	2017 - 2019								
Leon	2000 - 2021								
Mii	2012 - 2021								
Toledo	1999 - 2010	\bullet							
Toledo	2013 - 2019	\bullet							
BMS Function List									
Configure new	battery parame	ter							

16 Steering Column Electronics

SEAT Diagnostic	Funct	ion l	List	(Not	e:For r	referer	nce only)		
NOTES:										
• This function is supported.	<u>, , </u>	. 1		1	1	2 1 1	• 1			
* This function may be supported, which O This function is not supported.	depends	on the	e actu	al com	ndition of	t the veh	icle.			
▲ This function is the new feature in th	is vore	ion								
Vehicle		1011.				Year				
					200	100 - 2000	2			
<u>1M – Leon</u>										
<u>1M - Toledo</u>						99 - 2004				
<u>1P – Leon</u>						$\frac{16}{201}$				
3R - Exeo)9 - 2014				
5F - Ateca						7 - 202				
5F - Leon						3 - 2020				
5P - Altea)4 - 201				
5P - Altea XL						07 - 201				
5P - Freetrack					200	07 - 201	5			
5P - Toledo					200)5 - 2010	C			
6H - Arosa					200)1 - 2004	4			
6J - Ibiza					200)9 - 201'	7			
6K - Cordoba					199	9 - 200	2			
6K - Ibiza					199	9 - 2002	2			
6L – Cordoba						3 - 2009				
6L - Ibiza						$\frac{200}{2} - 2009$				
7M - Alhambra						$\frac{2}{1} - 2010$				
						1 - 202				
7N - Alhambra										
9K - Inca						$\frac{01 - 200}{2}$				
AA - Mii						2 - 202				
KJ – Arona						8 - 202				
KJ - Ibiza						8 - 202				
KL - Leon						20 - 202	1			
KM - Formentor						2021 -				
KN - Tarraco					201	9 - 202	1			
NH - Toledo					201	3 - 2019	9			
Systemlist	EcuInf o.		Erase Codes		Actuatio n Test	Basic Setting s	Adaptatio n	Securit y Login	Code II	Codin g
01 Engine Control Module 1							•		*	*
02 Transmission Control Module									*	*
03 Brakes 1					•		•		*	*
04 Steering Angle Sender							•		*	*
05 Kessy							•		*	*
06 Seat Adjustment Passenger Side							•		*	*
07 Display Control Unit							•		*	*
08 Air Conditioning					•				*	*
09 Central Electrics							•		*	*
OB Auxiliary Air Heater	•		•		•	•	•		×	*
OC Rear Axle Steering 2		•			•				×	× ×
OD Sliding Door Left		•							×	×
OE Media Player Position 1	•	•		•	•	•	•	•	× ×	× ×
OF Radio Tuner - Digital	•	•		•					× ×	× ×
10 Parking Assistance 2									× ×	× ×
		<u> </u>	<u> </u>						-	
11 Engine Control Module 2					•				×	× ×
12 Clutch Control Unit									×	× ×
13 Adaptive Cruise Control	•	•	•	•	•	•		•	×	× ×
14 Wheel Dampening Electronics	•	•	•	•	•			•	×	×
15 Airbag									*	*

•

•

•

•

్

*

17 Dash Board									*	*
18 Auxiliary Parking Heater					•				× ×	× ×
19 Gateway			•		•				× ×	× ×
1A Fuel Cell Engine			•	•	•	•	•		× ×	× ×
1B Active Steering			•						× ×	× ×
1C Vehicle Position Detection			•						× ×	× ×
1D Driver Identification									× ×	× ×
1E Media Player Position 2					•				× ×	*
20 High Beam Assistance			•	•	•				× ×	× ×
21 Battery Energy Control Module 2			•						× ×	× ×
22 All Wheel Control									× ×	× ×
23 Brake Boost									× ×	× ×
									_	
25 Immobilizer		•	•		•		•	•	*	*
26 Electronic Roof Control						•	•		*	*
27 Display Control Unit Rear	•		-	<u> </u>	•			•	*	*
28 Climate Control Unit Rear	•		•	•	•		•		*	*
29 Light Control Left					•		•	•	*	*
2A Control Unit Wireless Charging	•							•	*	*
2B Steering Column Locking	•	•	•	•	•			•	*	*
2D Voice Amplifier			•	•	•				*	*
2E Media Player Position 3			•	•					*	*
30 Special Function 2									*	*
31 Engine Electronics Group									*	*
32 Lock Electronics									*	*
33 All OBD Systems									*	*
34 Ride Control System				\bullet	•				*	*
35 Central Locking Control Module					•				*	*
36 Seat Adjustment Driver Side					•				*	*
37 Navigation					•				*	*
38 Roof Electronic Control Module	\bullet				•				*	*
39 Light Control Right	●				•				*	*
3A Special Vehicle Assistant									*	*
3B Sensor Electronics	\bullet								*	*
3C Lane Change Assistant									*	*
3D Special Function									*	*
3E Media Player Position 4					•				*	*
3F Dynamic Assembly Mounting	•				•				*	*
40 Air Conditioning Compressor	•				•				*	*
41 Diesel Pump Electronics					•				*	*
42 Door Electronics Driver Side					•				*	*
43 Bremskraftunterstutzung					•				*	*
44 Steering Assistance									*	*
45 Interior Monitoring									*	*
46 Central Module Comfort System	•	•			•	•	•	•	*	*
47 Sound System			•				•		×	*
48 Seat Adjustment Rear Driver Side	•		•		•				×	×
4A Rear Light	•		•		•				×	× ×
4B Multifunction Module			•		•	•	•		×	*
4C Tire Pressure Monitoring 2				•					× ×	× ×
4D Data Transfer Car2X XXX									× ×	× ×
4D Data Hanster Cal2A_AAA 4E Control Head Rear Right			•						× ×	× ×
4F Central Electrics 2									× ×	× ×
50 Seat Adjustment 3rd Row			•		•				× ×	× ×
			•	•					× ×	× ×
51 Drive Motor Control Module									_	
52 Door Electronics Passenger Side									<u>×</u>	× ×
53 Parking Brake			-		•				*	*
54 Rear Spoiler			•		•		•		*	*
55 Headlight Regulation					•				*	*

37 TV Inter	56 Radio					•				*	*
BR Fuel Supply Image: Control Control Image: Control Control Control Control Image: Control Control Control Control Control Image: Control Co				-							
BAL Long Ludinal Control Image: Control Dist in the image in th			<u> </u>	-						-	
BR Seat Adjustment Rear Passenger Side BR Seat Adjustment Rear Left Deparation Control Head Rear Left Deparation Deparati											
SC Lane Departure Warning System Set Control line depart left Set Set Migned depart left Set Migned depart										_	
DB Ogenation Set Control Part of the set of											
BE Control Head Rear Left <											
Bit Information Control Unit 1 Image: Control Control Control Unit 1 Image: Control										-	
60 Tachograph 60 Tachograph 61 Baltiery Regulation 62 Door Electronics Rear Left 63 Statilizers 64 Stabilizers 65 Seat Adjustment Rear 65 Seat Adjustment Rear 66 Seat Adjustment Rear 67 Voice Control 68 Barty Assistance 69 Trailer Pressure 60 Dock Lide Control Unit 60 Dock Lide Control Unit 61 Baptay Control Unit 62 Dock Lide Control Unit 63 Barty Control Roof 64 Dock Lide Control Unit 65 Dock Lide Control Unit 66 Dock Lide Control Unit 67 Control Roof 70 Deck Lide Control Roof 71 Rattery Charger 72 Dock Lide Control Unit 73 Toleagen Roof Roof Roof Roof Roof Roof Roof Roo											
61 Battery Regulation • • • • • • • *											
62 Door Ilectronics Rear Left • <t< td=""><td></td><td></td><td></td><td></td><td></td><td>•</td><td></td><td></td><td></td><td></td><td></td></t<>						•					
G3 Entry Assistance Driver Side •		•	<u> </u>	-		•				_	
64 Stabilizers 65 Tire Pressure Monitoring 1 6<			•	<u> </u>		•				-	
65 Tire Prossure Monitoring 1 • <t< td=""><td></td><td><u> </u></td><td>•</td><td></td><td></td><td>•</td><td></td><td></td><td></td><td></td><td></td></t<>		<u> </u>	•			•					
66 Seat Adjustment Rear • • • • • * <td></td> <td>•</td> <td>•</td> <td>•</td> <td></td> <td>•</td> <td></td> <td>•</td> <td></td> <td>_</td> <td></td>		•	•	•		•		•		_	
67 Yoice Control • • • • • • *		•	•			•	•				
88 Wiper Control Unit 9 89 Wiper Control Unit 9 80 Trailer Function 9 80 Trailer Function 9 80 Trailer Function 9 80 Trailer Function 9 80 80 80 Trailer Function 9 80 80 80 80 80 80 80 80 80 80 80 80 80										-	
69 Trailer Function • • • • • • • * <td></td> <td>•</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>•</td> <td></td> <td>-</td> <td></td>		•						•		-	
6A Door Automatic Rear Driver Side 6B Aerodynamics Control Unit 6C Camera System Rear View 6D Deck Lid Control Unit 6E Display Control Roof 6E Display Control Roof 6E Orborn Module Comfort System 2 71 Bettry Charger 71 Bettry Charger 72 Door Electronics Rear Right 73 Telemasistance 74 Chassis Control 75 Telematics Communication Unit 76 Parking Assistance 77 Telephone 78 Slidling Door Right 71 Battry Maskistance 77 Telephone 77 Telephone 78 Slidling Door Right 70 Automatic Rear Passenger Side 70 Automatic Rear Passenger Side 70 Parking Heater 71 Information Control Unit 2 72 Information Control Unit 2 74 Chassis Control 75 Parking Assistance 76 Parking Assistance 77 Telephone 78 Slidling Door Right 78 Slidling Door Right 79 Daviliary Heater 70 Automatic Rear Passenger Side 70 Automatic Rear Passenger Side 71 Information Control Unit 2 72 Marking Assistance 74 Night Yision 75 Rear Shift Control Module 76 Parking Assistance 77 Slephone 78 Slephone 79 Aviliary Heater 70 Automatic Rear Passenger Side 70 Automatic Rear Passenger Side 70 Automatic Rear Passenger Side 71 Information Control Unit 2 <						•					
6B. Acrodynamics Control Unit 6C Cancra System Rear View 6D Deck Lid Control Unit 6F Display Control Roof 7 Entry Charger 71 Eattery Charger 72 Door Electronics Rear Right 73 Entry Assistance Passenger Side 74 Chassis Control 75 Telematics Communication Unit 76 Parking Assistance 77 Telephone 78 Stiding Door Right 79 Dork Lictron Not Unit 70 Door Night 71 Telephone 72 Boor Sight 74 Davis Sistance 75 Telematics Communication Unit 76 Parking Assistance 77 Telephone 78 Stiding Door Right 78 Stiding Door Right 79 Assistance 70 Lauranatic Rear Passenger Side 71 Liormatic Communication Unit 72 Door Automatic Rear Passenger Side 73 Elematics Communication Unit 74 Lauranatic Rear Passenger Side 75 Lauranatic Rear Passenger Side 76 Lauranatic Rear Passenger Side 77 Liormatic Rear Passenger Side 78 Stiding Door Right 79 Lauranatic Rear Passenger Side 70 Auxiliary Heater 71 Liormatic Rear Passenger Side 72 Lauranatic Rear Passenger Side 74 Lauranatic Rear Passenger Side 75 Lauranatic Rear Passenger Side 76 Lauranatic Rear Passenger Side 77 Liormatic Rear Pa	69 Trailer Function	•				•					
6C Camera System Rear View • • • • • * <	6A Door Automatic Rear Driver Side	•				•					
6D Deck Lid Control Unit 6E Display Control Roof 6F Central Module Comfort System 2 71 Battery Charger 72 Door Electronics Rear Right 73 Entry Assistance Passenger Side 74 Chassis Control 75 Telematics Communication Unit 76 Parking Assistance 77 Telephone 78 Sliding Door Right 70 Auxiliary Heater 71 Battery Rearen 72 Door Automatic Rear Passenger Side 74 Chassis Control 75 Telephone 76 Parking Assistance 77 Telephone 70 Auxiliary Heater 71 Battery Reater 72 Door Automatic Rear Passenger Side 74 Auxiliary Reater 75 Del Control Unit 2 76 Dark Lide Control Unit 2 77 Elephone 78 Sliding Door Right 79 Auxiliary Heater 70 Auxiliary Reater 71 Battery Regulation Auxiliary 72 Battery Regulation Auxiliary 73 Lene Assist LT3 74 Lane Assist LT3 75 Lane Assist LT3 76 Audit Control Seare Passenger Side 70 Autionur Seat Reare Passenger Side 70 Dourour Seat Reare Passenger Side 70 Autionur Seat Reare Passenger Side 70 Autionur Seat Reare Passenger Side 71 Lane Assist LT3 72 Lane Assist LT3 73 Battery Rearer Side 74 Auxiliary 75 Doard Camera 76 Autonur Seat Reare Passenger Side 76 Auxiliary 77 Auxiliary <td>6B Aerodynamics Control Unit</td> <td></td> <td></td> <td></td> <td></td> <td>•</td> <td></td> <td></td> <td></td> <td></td> <td></td>	6B Aerodynamics Control Unit					•					
6E Display Control Roof • • • • • • • • • *	6C Camera System Rear View										
6F Central Module Comfort System 2 • • • • • *	6D Deck Lid Control Unit									*	*
71 Battery Charger • • • • • * <td>6E Display Control Roof</td> <td>•</td> <td></td> <td></td> <td></td> <td>•</td> <td></td> <td>•</td> <td></td> <td>*</td> <td>*</td>	6E Display Control Roof	•				•		•		*	*
71 Battery Charger • • • • • • * <td>6F Central Module Comfort System 2</td> <td>•</td> <td></td> <td></td> <td></td> <td>•</td> <td></td> <td></td> <td></td> <td>*</td> <td>*</td>	6F Central Module Comfort System 2	•				•				*	*
72 Door Electronics Rear Right 73 Entry Assistance Passenger Side 74 Chassis Control 75 Telematics Communication Unit 76 Parking Assistance 77 Telephone 78 Sliding Door Right 70 Door Automatic Rear Passenger Side 70 Daviliary Heater 70 Daviliary Heater 71 Information Control Unit 2 76 Parking Assistance 70 Daviliary Heater 70 Daviliary Heater 71 Bash Board Display Unit 71 Information Control Unit 2 72 Elease Sift Control Module 82 Head Up Display 84 Night Vision 85 On-Board Camera 89 Multi Contour Seat Driver Side 89 Multi Contour Seat Driver Side 89 Multi Contour Seat Passenger Side 90 Multi Contour Seat Rear Driver Side 90 Pretensioner Front Left 90 Pretensioner Front Left 90 Pretensioner Front Left 90 Pretensioner Front Left 91 Engine Control Module (ECM) 92 Transmission Electronics 93 Immobilizer 94 Airbay (SRS)		•						•		*	*
73 Entry Assistance Passenger Side 74 Chassis Control 75 Telematics Communication Unit 76 Parking Assistance 77 Telephone 77 Telephone 78 Sliding Door Right 70 Door Automatic Rear Passenger Side 70 Auxiliary Heater 71 Dash Board Display Unit 78 B Datry Regulation Auxiliary Accumulator 1 81 Gear Shift Control Module 82 Head Up Display 84 Night Vision 85 On-Board Camera 87 Lane Assist LT3 88 Multi Contour Seat Parsenger Side 90 Multi Contour Seat Parsenger Side 91 Multi Contour Seat Parsenger Side 92 Multi Contour Seat Parsenger Side 94 Mithic Contour Seat Parsenger Side 95 Multi Contour Seat Parsenger Side 96 Multi Contour Seat Parsenger Side 90 Pretensioner Front Left 90 Pretensioner Front Left 90 Pretensioner Front Left 90 Pretensioner Front Left 91 Image Notaul (EKM) 93 Immobilizer 94 Airbag (SRS)		•				•		•			
74 Chassis Control 75 Telematics Communication Unit 76 Parking Assistance 76 Parking Assistance 77 Telephone 9 9 78 Sliding Door Right 78 Sliding Door Right 9 9 70 Auxiliary Heater 9 9 9<		•				•					
75 Telematics Communication Unit 76 Parking Assistance 77 Telephone 78 Sliding Door Right 78 Sliding Door Right 70 Automatic Rear Passenger Side 70 Automatic Rear Passenger Side 70 Automatic Rear Passenger Side 71 Telephone 72 Dash Board Display Unit 71 Telephone 72 Telephone 73 Sliding Door Right 70 Automatic Rear Passenger Side 71 Dash Board Display Unit 72 Telephone 73 Sliding Door Right 74 Dash Board Display Unit 75 Telephone 75 Telephone 76 Parking Sarking Control Module 76 Parking Sarking Control Module 75 Telephone 75 Telephone 81 Gear Shift Control Module 75 Telephone 81 Night Vision 82 Iead Up Display 84 Night Vision 85 Dn-Board Camera 87 Lane Assist LT3 88 Multi Contour Seat Passenger Side 90 Multi Contour Seat Passenger Side 91 Multi Contour Seat Rear Driver Side 88 Adaptive Cruise Control 2 90 Pretensioner Front Left 90 Pretensioner Front Right 91 Engine Control Module 92 Transmission Electronics 93 Immobilizer 94 Airbag (SRS)		•				•					
76 Parking Assistance 77 Telephone 77 Telephone 78 Sliding Door Right 70 Dor Automatic Rear Passenger Side 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 91 <td></td> <td>•</td> <td>•</td> <td>•</td> <td></td> <td>•</td> <td></td> <td></td> <td></td> <td></td> <td></td>		•	•	•		•					
77 Telephone 78 Sliding Door Right 78 Sliding Door Right 78 Sliding Door Right 78 Sliding Door Right 70 Auxiliary Heater 70 Auxiliary Heater 77 Dask Board Display Unit 79 Dask Board Display Unit 70 Dask Board Display Unit 71 Information Control Unit 2 80 Battery Regulation Auxiliary Accumulator 1 81 Gear Shift Control Module 82 Head Up Display 84 Night Vision 85 On-Board Camera 87 Lane Assist LT3 88 Multi Contour Seat Driver Side 89 Multi Contour Seat Passenger Side 80 Multi Contour Seat Passenger Side 81 Battery Energy Control Module 82 Head Up Display 90 Multi Contour Seat Rear Passenger Side 91 Empine Control Module 92 Transmissione Front Right 91 Empine Control Module (ECM) 91 Empine Control Module (ECM) 92 Transmission Electronics 94 Airbag (SRS) 95 Onedat Contour Seat Rear Passenger Side 96 Onedat		•				•		•			
78 Sliding Door Right • • • • • • • • • * <td></td> <td>•</td> <td>•</td> <td>•</td> <td></td> <td>•</td> <td>•</td> <td>•</td> <td>•</td> <td></td> <td></td>		•	•	•		•	•	•	•		
7A Door Automatic Rear Passenger Side 7D Auxiliary Heater 7D Auxiliary Heater 7E Dash Board Display Unit 7E Dash Board Display Unit 7F Information Control Unit 2 80 Battery Regulation Auxiliary Accumulator 1 81 Gear Shift Control Module 82 Head Up Display 84 Night Vision 85 On-Board Camera 87 Tane Assist LT3 88 Multi Contour Seat Driver Side 89 Multi Contour Seat Rear Driver Side 80 Adaptive Cruise Control Module 81 Badaptive Cruise Control 2 82 Hear Processing Electronics 80 Multi Contour Seat Rear Driver Side 80 Adaptive Cruise Control 2 80 Battery Energy Control Module 81 Badaptive Cruise Control 2 82 Hange Processing Electronics 83 Pretensioner Front Left 90 Pretensioner Front Right 91 Engine Control Module (ECM) 92 Transmission Electronics 91 Engine Control Module (ECM) 92 Transmission Electronics 94 Airbag (SRS)			•			•	•	•	•		
7D Auxiliary Heater •		•									
7E Dash Board Display Unit •		•				•					
7F Information Control Unit 2 • • • • • • • * <td></td>											
80 Battery Regulation Auxiliary Accumulator 1 • • • • • • • • • • *			-	_	–						
Accumulator 1••••••*** <t< td=""><td></td><td>•</td><td></td><td>-</td><td></td><td>•</td><td></td><td></td><td></td><td>~</td><td></td></t<>		•		-		•				~	
81 Gear Shift Control Module • <td< td=""><td></td><td>\bullet</td><td></td><td></td><td></td><td>•</td><td></td><td></td><td></td><td>*</td><td>*</td></td<>		\bullet				•				*	*
82 Head Up Display • • • • • • • • *		•				•		•		*	*
84 Night Vision •		•				•					
85 On-Board Camera • • • • • • • *										-	
87 Lane Assist LT3•••••••****88 Multi Contour Seat Driver Side•••••••****80 Multi Contour Seat Rear Driver Side•••••••*****80 Multi Contour Seat Rear Driver Side•••••••***										_	
88 Multi Contour Seat Driver Side • • • • • • • *				-							
89 Multi Contour Seat Passenger Side • • • • • • *				-		-		-	-		
8A Multi Contour Seat Rear Driver Side•••••••**8B Adaptive Cruise Control 2••••••••***<				_							
8B Adaptive Cruise Control 2 • <td< td=""><td></td><td></td><td></td><td>-</td><td></td><td></td><td></td><td></td><td></td><td>-</td><td></td></td<>				-						-	
8C Battery Energy Control ModuleImage Processing ElectronicsImage Processing Electronics				-						_	
8D Multi Contour Seat Rear Passenger Side••••••••••***8E Image Processing Electronics•••••••••••**			-	-				•			
8E Image Processing Electronics••••••••***8F Pretensioner Front Left••••••••••**		•		-		•					
8F Pretensioner Front Left•••••••••••***90 Pretensioner Front Right••••••••••***		•		-		•					
90 Pretensioner Front Right••••••••***91 Engine Control Module (ECM)••••••••••**		•				•					
91 Engine Control Module (ECM)•••••••••***92 Transmission Electronics•••••••••**						•					
92 Transmission Electronics•••••••**93 Immobilizer•••••••••***94 Airbag (SRS)•••••••••***				-		•					
93 Immobilizer •	91 Engine Control Module (ECM)	•		_		•				_	
94 Airbag (SRS) • • • • • • • • • • • • • • • • • • •	92 Transmission Electronics										
	93 Immobilizer					\bullet				※	※
95 Electronic Stability Program 🛛 🔍 🔍 🔍 🔍 🔍 🖉 👋 🖉	94 Airbag (SRS)										
	95 Electronic Stability Program									*	*

Der Heindern Der Keiner Der Keiner<	96 Instrument Cluster	•			•				*	*
BS Tirc Pressure Wonlowing Image: Section of the s										
99 Electrical Ignition/starter Switch •									_	
SA Resort Control										
BP. Driver's Door Electronics Image: Second Se					 				_	
Sc A/C Ellectronics					 					
96 Auxillary Beater (fuel) 9 </td <td></td>										
9E Availlary Hoater (Electric) Image: Second Secon										
gF Parking Heater, Tater <td< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></td<>										
Montio 5 Badio, Image 1 Image 2 Imagee					 				_	
AL Navigation AL		•			 •					
A2 CD Changer A3 Tolephone A5 Front Sensors Driver Assistance System A6 Microphone Control Unit A7 Infotainment Interface A1 Infotainment Interface A8 External Communication Interface A8 Mineel Brack Rear Right A9 Actuator For Structure-Borno Sound A8 Theol Brack Rear Right A8 Theol Brack Rear Right A8 Theol Brack Rear Right A9 Actuator For Structure-Borno Sound A8 Theol Brack Rear Right A9 Actuator For Structure-Borno Sound A8 Theol Brack Rear Right A9 Endometry Interface A8 Theol Brack Rear Right A9 Endometry Interface A8 Toleparty Interface A8 Theol Brack Rear Right A9 Actuator For Structure-Borno Read Rear Right B9 Regrammable Special Module B9 Auxiliary Display Control Woule B9 Auxiliary Display Control Unit B9 Auxiliary Display Control Note B9 Auxiliary Display Control Note B9 Auxiliary Display Control Note B9 Auxiliary Display Control Unit B9 Auxiliary Display Control Note B9 Auxiliary Display Control Note B9 Auxiliary Display Control Note B9 Con Electronics Rear Passenger Side B0 Cone		•			•					
Na Telephone Ab Front Sensors Driver Assistance System Ab Microphone Control Luit Ab Necole Communication Interface Ab Necole Communication Interface Ab Necole Communication Interface Ab Necole Brake Rear Right Ab Necole Brake Rear Right Ab Sensors Brake Systems Ab Sensors Brake Systems Ab Sensors Brake Systems Ab Sensors Brake Systems Ab Real Brake Rear Right Ab Sensors Brake Systems Ab Real Brake Rear Right Ab Sensors Brake Systems Ab Real Brake Systems <		•			•	•	•	•		
A5 Front Sensors Driver Assistance System A6 Microphone Control Unit A7 Infotainment Interface A8 External Communication Interface A8 External Communication Interface A9 Actuator For Structure-Forne Sound A8 Hacel Brake Rear Right A8 Hacel Brake Rear Right A9 Actuator For Structure-Forne Sound A0 Sensors Brake Systems A0 Sensors Brake Systems B1 Oper Operating Field B1 Oper Operating Sound Unit B6 Steering Column Jacket Switch Module B7 Access Startsystem Interface B9 Auxiliary Display/control Unit B1 Access Startsystem Interface B9 Auxiliary Display Control Unit B1 Access Startsystem Interface B9 Auxiliary Display Control Unit B1 Shiding Door Rear Right C0 Actuator For Exterior Noise C1 Battery Regulation C2 Transmission Control Module 2 C3 D		•			•					
AG Microphone Control Unit AT Infotainment Interface AT Infotainment Interface AS External Communication Interface AS External Communication Interface AM these Extractor Fore Sound A Hose Extractor Control Module A C Reductant Control Module A C Reductant Control Unit A C Reductant Control Head (Roof K		•			 •					
AT Infortainment Interface M8 External Communication Interface M9 Actuator For Structure-Borne Sound AM Area Brake Rear Right M8 Broel Brake Rear Right M8 Broel Brake Rear Right M8 Broel Brake Rear Left M8 Broel Brake Rear Left M8 Telemetry Diagnostic Control Unit M8 Telemetry Diagnostic Control M8 Telemetry Diagnostic Control Diit M9 Telemetry Diagnostic Control Diit M9 Telemetry Display Control Unit M8 Deperial Module M9 Telemetry Display Control Unit M8 Deperial Monu		•	•	•	<u> </u>			•		
AB External Communication Interface A9 Actuator For Structure-Borne Sound A8 Neel Brake Rear Right A8 Meel Brake Rear Left A8 Meel Brake Rear Left A8 Action Control Module A9 Action Control Module A6 Action Control Module A8 Action Control Module A8 Action Control Module A8 Action Control Head (Roof Control Head) Action Control Head (Roof B1 Diper Operating Field B2 Action Control Head (Roof B1 Action Control Head (Roof Control Head) Action Control Head (Roof B1 Action Control Control Head (Roof B1 Action Control Control Head (Roof B1 Action Control Control Control Control Control B2 Action Control Control B5 Action Control Control B6 Action Control Control B6 Action Control Control Control B6 Action Control Control Control B6 Action Control Control Control B7 Action Control Control Control B6 Action Control Control Control B6 Action Control Control Control B7 Action Control Control Control B8 Action Control Control Control		•	•		•	•	•	•		
A9 Actuator For Structure-Borne Sound AA Wheel Brake Rear Right AB Wheel Brake Rear Right AB Wheel Brake Rear Right AB Wheel Brake Rear Left AC Reductant Control Module AC Reductant Contr		•	•	•	•			•		
A4 Theel Brake Rear Right AB Theel Brake Rear Left AB Theel Brake Rear Left AC Reductant Control Module AD Sensors Brake Systems BD Hoper Operating Field BD Forgrammable Special Module AD Sensors Brake System Interface AD Sensors Brake System Interface AD Sensors Brake System Interface AD Sensor Brake Source Unit AD Sensor Brake Source Diver Side BD Nor Electronics Rear Driver Side BD Night Yoltage Battery Charge Management AD Sensor Show Control Module 3 AD Sensor Show Control Module		•	•	•	•			•		
AB Wheel Brake Rear Left AC Reductant Corrol Modulo AC Reductant Corrol Modulo AD Sensors Brake Systems AE Telemetry Diagnostic Control Unit BO Roof Display/control Head (Roof Control Head) B1 Upper Operating Field B2 Parking Aid B2 Parking Aid B3 Trailer Function B4 Felenetry Diagnostic Control Module B2 Parking Aid B3 Trailer Function B4 Wheile Electrical System Control Module B5 Programmable Special Module B6 Steering Column Jacket Switch Module B7 Access Startsystem Interface B9 Auxiliary Display Control Unit B7 Boor Electronics Rear Driver Side B7 Boor Electronics Rear Passengor Side B0 Bilding Door Rear Left B7 Sliding Door Rear Left B8 Sleeroning Control Module 2 C9 Rear		<u> </u>	•	•	 •			•		
AC Reductant Control Module Mo Sensors Brake Systems Mo Sensors Brake		•		•						
AD Sensors Brake Systems AE Telemetry Diagnostic Control Unit BO Roof Display/control Head (Roof Control Head) Bill Upper Operating Field AB Telemetry Diagnostic Control AB Telemetry Diagnostic Control AE Telemetry Diagnostic Control AB Telemetry Diagnostic Control AD Telemetry Diagnostic Control AB Telemetry Diagnostic Control AD Telemetry Diagnostic Control Module AD Telemetry Diagnostic Control Module AD Telemetry Diagnostic Control Module AD Telemetry Regulation AD Telemetry Regulation AD Telemetry Regulation 		•			•				_	
AE Telemetry Diagnostic Control Unit D0 Roof Display/control Head (Roof Control Head) B1 Upper Operating Field B2 Parking Aid B3 Trailor Function B4 Vehicle Electrical System Control Module B5 Programmable Special Module B6 Steering Column Jacket Switch Module B7 Access Startsystem Interface B8 Electronic Roof Control 2 B8 Belectronic Roof Control 1 B8 Assembly Mounting B8 Door Electronics Rear Driver Side B9 High Voltage Battery Charge Management B5 Sliding Door Rear Left B6 Sliding Door Rear Left B6 Sliding Door Rear Left B7 Sliding Door Rear Right C1 Battery Regulation C0 Actuator For Exterior Noise C1 Battery Charge Management C6 Startsyston Control Module 2 C6 Startery Supplay Control Unit 2 B7 Sliding Door Rear Left C0 Actuator For Exterior Noise C1 Battery Regulation C6 Startery Regulation C7 redestrian Protection C6 Battery Charge Control Module 2 C6 Battery Charge Control Module 3 C6 Battery Charge Control Module 4 C6 Startery Regulation C7 redestrian Protection C6 Startery Charge Control Module 2 C8 Control Module 3 C6 Starter / Generator Noise C6 Bartery Charge Control Module 4 C6 Bartery Charge Control Module 4 C7 redestrian Protection C7 redestrian Protection C6 B		•	•		•	•				
B0 Roof Display/control Head (Roof Control Head B1 B1 B1 B2 Parking Aid B2 Parking Aid B3 B1 B1 B1 B1 B2 Parking Aid B3 B3 B3 B3 B4 Parking Aid B3 B4 B4 B4 B4 B4 B4 B4 B4 B4 B4 B4 B4 B5 Programmable Special Module B5 B6 Steering Column Jacket Switch Module B6 B6 B6 Control Rear Driver Side B7 B6 B1 B1 B1 B1 B1 B1 B1 B1 B1 B2 B1 B2		•	•	-	•			•		
Control Head) Image: Control Head) B1 Upper Operating Field B2 Parking Aid B2 Tarking Aid B3 Trailer Function B4 Vehicle Electrical System Control Module B4 Vehicle Electrical System Control Module B5 Programmable Special Module B6 Steering Column Jacket Switch Module B7 Access Startsystem Interface B8 Electronic Roof Control 2 B8 Electronic Roof Control 2 B9 Auxiliary Display Control Unit B9 Door Electronics Rear Driver Side B0 Door Electronics Rear Passenger Side B6 Stiding Door Rear Left B7 Sliding Door Rear Right C0 Actuator For Exterior Noise C1 Battery Regulation C2 Transmission Control Module C3 Drive Motor Control Module C4 DC/DC Converter Control Module C6 Battery Regulation C6 Battery Regulation C6 Battery Control Module C6 Battery Control Module C6 Battery Control Module C6 Battery Control Module C7 Pedestrian Protection C6 Battery Control Module C9 Rear Mirror C6 Battery Control Module C0 Rear Aras Pastering C6 Battery Control Module C6 Battery Control Modul		•					•		*	*
Control Head B1 Upper Operating Field B2 Parking Aid B3 Trailer Function B4 Vehicle Electrical System Control Module B6 Steering Column Jacket Switch Module B6 Steering Column Jacket Switch Module B6 Steering Column Jacket Switch Module B7 Access Startsystem Interface B9 Auxiliary Display Control Unit B9 Auxiliary Display Control Unit B0 Dor Electronics Rear Driver Side B0 High Voltage Battery Charge Management B1 Sliding Door Rear Left B7 Sliding Door Rear Right C0 Actuator For Exterior Noise C1 Battery Regulation C3 Drive Motor Control Module C4 C/DC Converter Control Module C4 C/DC Converter Control Module C6 Battery Charge Control Module C7 Pedestrian Fried C6 Battery Charge Control Module C6 Battery Charge Control Module C7 Pedestrian Fried C6 Battery Charge Control Module C6 Battery Charge Control Module C7 Pedestrian Fried C6 Battery Charge Control Module C7 Pedestrian Protection C6 Battery Charge Control Module		•		•	•		•	•	*	*
B2 Parking Aid B3 Trailer Function B4 Vehicle Electrical System Control Module B5 Programmable Special Module B6 Steering Column Jacket Switch Module B7 Access Startsystem Interface B7 Access Startsystem Interface B8 Electronic Roof Control 2 B8 Assembly Mounting B8 Door Electronics Rear Driver Side B0 Dor Electronics Rear Passenger Side B1 High Voltage Battery Charge Management B5 Sliding Door Rear Right C1 Battery Regulation C2 Transmission Control Module 3 C5 Thermal Management C6 Battery Charge Control Module C9 Rear Mind Moule 3 C7 Pedestrian Protection C6 Battery Charge Control Module C6 Battery Charge Control Module C6 Battery Charge Control Module 4 C9 Rear Mind Management C9 Rear Mind Management C9 Rear Mind Module 3 C7 Pedestrian Protection C6 Battery Charge Control Module C6 Battery Charge Control Module C9 Rear Mind Management C6 Battery Charge Control Module C6 Battery Charge Control Module C9 Rear Mind Management C6 Battery Charge Control Module C6 Battery Charge Control Module C9 Rear Mind Management C6 Battery Charge Control Module C6 Battery Charge Control Module C6 Battery Charge Control Module C7 Pedestrian Protection C6 Battery Charge Control Module C6 Battery Charge Control M		-		-	-					
B3 Trailer Function B4 Vehicle Electrical System Control Module B5 Programmable Special Module B6 Steering Column Jacket Switch Module B7 Access Startsystem Interface B8 Electronic Roof Control 2 B8 Electronic Roof Control 1 B9 Auxiliary Display Control Unit B0 Dor Electronics Rear Driver Side B0 High Voltage Battery Charge Management B0 High Voltage Battery Charge Management C0 Actuator For Exterior Noise C1 Battery Regulation C2 Transmission Control Module C3 Drive Motor Control Module C4 DC/DC Converter Control Module C6 Battery Charge Control Unit 2 C6 Battery Control Module 3 C7 Pedestrian Protection C6 Battery Charge Monage C7 Pedestrian Protection C6 Battery Charge Monage C7 Pedestrian Protection C6 Battery Charge Monage C7 Pedestrian Protection C6 Battery Charge Control Module C7 Pedestrian Protection C6 Battery Charge Control Module C7 Pedestrian Protection C6 Battery Charge Control		•			 •				_	
B4 Vehicle Electrical System Control Module B5 Programmable Special Module B6 Steering Column Jacket Switch Module B6 Steering Column Jacket Switch Module B7 Access Startsystem Interface B7 Access Startsystem Interface B9 Auxiliary Display Control Unit B9 Auxiliary Display Control Unit B0 Dor Electronics Rear Driver Side B0 High Voltage Battery Charge Management B0 High Voltage Battery Charge Management B1 High Voltage Battery Charge Management B7 Sliding Door Rear Right C0 Actuator For Exterior Noise C1 Battery Regulation C2 Transmission Control Module C3 Drive Motor Control Module C4 DC/DC Converter Control Module C6 Battery Charge Control Unit 2 C9 Rear Mirror C9 Rear Axle Steering C6 Battery Charge Control Unit 2 C6 Battery Charge Control Module C6 Battery Control Module C7 Pedestrian Protection C9 Rear Axle Steering C0 Actuator For Sunroof C0 Actuator For Sunroof C6 Battery Control Module C6 Battery Control Module C6 Battery Control Module C7 Pedestrian Protection C6 Battery Control Module C6 Battery Charge Control Module C6 Battery Charge Control Module C7 Pedest		•		•	•			•		
ModuleModul		•	•		•	•	•	•	*	<u>×</u>
B5 Programmable Special Module B6 Stering Column Jacket Switch Module B7 Access Startsystem Interface B7 Access Startsystem Interface B8 Electronic Roof Control 2 B8 Electronic Roof Control 12 B9 Auxiliary Display Control Unit B0 Door Electronics Rear Driver Side B0 Door Electronics Rear Driver Side B0 Door Rear Rear Passenger Side B1 High Voltage Battery Charge Management B1 Electronics Rear Passenger Side B1 High Voltage Battery Charge Management B1 Electronics Rear Passenger Side B2 Sliding Door Rear Right C0 Actuator For Exterior Noise C1 Battery Regulation C2 Transmission Control Module 2 C3 Drive Motor Control Module C4 DC/DC Converter Control Module C5 Thermal Management C6 Battery Charge Control Unit 2 C6 Battery Charge Control Module C7 Pedestrian Protection C6 Battery Charger Control Module C6 Battery Charger Control Module C6 Battery Charger Control Module C6 Battery Charger Control Unit 2 C6 Battery Charger Control Module C7 Pedestrian Protection C6 Battery Charger Control Module C6 Battery Charger Control Module C6 Battery Charger Control Module C7 Predestrian Protection C6 Battery Charger Control Module C6 Battery Charger Control Module </td <td></td> <td>\bullet</td> <td></td> <td>•</td> <td>•</td> <td>•</td> <td>•</td> <td>•</td> <td>*</td> <td>*</td>		\bullet		•	•	•	•	•	*	*
B6 Steering Column Jacket Switch Module B7 Access Startsystem Interface B8 Electronic Roof Control 2 B9 Auxiliary Display Control Unit BA Assembly Mounting BA Assembly Mounting BB Door Electronics Rear Driver Side B0 Door Electronics Rear Driver Side B0 High Voltage Battery Charge Management BF Sliding Door Rear Right C0 Actuator For Exterior Noise C1 Battery Regulation C2 Transmission Control Module 2 C3 Drive Motor Control Module 3 C4 DC/DC Converter Control Module C6 Battery Charge Control Unit 2 C6 Battery Charge Control Module C7 Pedestrian Protection C8 Auxiliary Display Control Unit 2 C6 Battery Charge Control Module C7 Pedestrian Protection C6 Battery Charge Control Module C6 Battery Charger Control Module <									*	**
B7 Access Startsystem Interface B8 Electronic Roof Control 2 B8 Electronic Roof Control 1 B9 Auxiliary Display Control Unit B1 Assembly Mounting BA Assembly Mounting B2 Door Electronics Rear Driver Side B0 Door Electronics Rear Passenger Side B0 Door Electronics Rear Passenger Side B1 High Voltage Battery Charge Management B2 Sliding Door Rear Left B5 Sliding Door Rear Right C0 Actuator For Exterior Noise C1 Battery Regulation C2 Transmission Control Module 2 C3 Drive Motor Control Module C4 DC/DC Converter Control Module C6 Battery Charger Control Module C7 Pedestrian Protection C6 Battery Charger Control Module C7 Pedestrian Protection C6 Battery Charger Control Module C7 Pedestrian Protection C6 Battery Charger Control Module C6 Battery Charger Control Module C7 Pedestrian Protection C6 Battery Charger Control Module C7 Pedestrian Protection C6 Battery Charger Contr										
B8 Electronic Roof Control 2 B9 Auxiliary Display Control Unit B9 Auxiliary Display Control Unit B0 B4 B4 B5 B0 cor Electronics Rear Driver Side B0 B0 B0 B0 B1 B1 B0 B1 B1 B1 B1 B1 B1 B1 B1 B1 B2 B2 B2 B2 B2 B2 B2 B2 B2 B2 B2 B2 B3 B4 B4 B4 B4 B4 B5 B1 B2 B4 B4 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 B5 <td< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></td<>										
B9 Auxiliary Display Control Unit BA Assembly Mounting BA Assembly Mounting BA Assembly Mounting BB Door Electronics Rear Driver Side BC Door Electronics Rear Passenger Side BD High Voltage Battery Charge Management BE Sliding Door Rear Left BF Sliding Door Rear Right C0 Actuator For Exterior Noise C1 Battery Regulation C2 Transmission Control Module 2 C3 Drive Motor Control Module C4 DC/DC Converter Control Module C5 Thermal Management C6 Battery Charger Control Unit 2 C6 Battery Charger Control Module C7 Pedestrian Protection C6 Battery Charger Control Module C7 Pedestrian Protection C8 Auxiliary Display Control Unit 2 C9 Rear Mirror C9 Rear Akle Steering CC Starter / Generator Control Module C6 Battery Control Module C6 Battery Control Module C6 Battery Control Module C6 Battery Charger Control Module C6 Battery Charger Control Module C7 Pedestri										
BA Assembly Mounting • • • • • • • * * * BB Door Electronics Rear Driver Side • • • • • • * * * * BC Door Electronics Rear Passenger Side • • • • • • *<										
BB Door Electronics Rear Driver Side • • • • • • * * * BC Door Electronics Rear Passenger Side • • • • • • * <td></td> <td></td> <td>—</td> <td>-</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>			—	-						
BC Door Electronics Rear Passenger Side BD High Voltage Battery Charge Management ES Sliding Door Rear Left BF Sliding Door Rear Right Co Actuator For Exterior Noise C1 Battery Regulation C2 Transmission Control Module 2 C3 Drive Motor Control Module C4 DC/DC Converter Control Module C6 Battery Charger Control Module C7 Pedestrian Protection C7 Pedestrian Protection C8 Auxiliary Display Control Unit 2 C9 Rear Mirror C9 Rear Mirror C9 Rear Axle Steering C6 Battery Control Module C4 Dotrol Module For Sunroof C4 Dotrol Module For Sunroof C4 Dotrol Module For Sunroof C5 Thermal Management C5 Derive Motor Control Module C6 Battery Charger Control Module C6 Battery Charger Control Module C6 Battery Charger Control Module C6 Drive Motor Control Module C6 Drive M	· · · · · · · · · · · · · · · · · · ·								_	
BD High Voltage Battery Charge Management BE Sliding Door Rear Left BF Sliding Door Rear Right Co Actuator For Exterior Noise C1 Battery Regulation C1 Battery Regulation C2 Transmission Control Module 2 C3 Drive Motor Control Module 3 C4 DC/DC Converter Control Module C5 Thermal Management C6 Battery Charger Control Module C7 Pedestrian Protection C8 Auxiliary Display Control Unit 2 C9 Rear Mirror C9 Rear Mirror C9 Rear Axle Steering C6 Batter / Generator Control Module C4 Dchrol Module For Sunroof C4 Dchrol Module For Sunroof C4 Dchrol Module S C5 Thermal Steering C6 Batter / Generator Control Module C9 Rear Axle Steering C6 Batter / Generator Control Module C5 Drive Motor Control Module C6 Drive Motor Control Module C7 Pedestrian Protection C6 Drive Motor Control Module C6 Drive Motor Control Module <				-						
BE Sliding Door Rear Left BF Sliding Door Rear Right C0 Actuator For Exterior Noise C1 Battery Regulation C2 Transmission Control Module 2 C3 Drive Motor Control Module 3 C4 DC/DC Converter Control Module C5 Thermal Management C6 Battery Charger Control Module C7 Pedestrian Protection C8 Auxiliary Display Control Unit 2 C9 Rear Mirror C9 Rear Axle Steering C0 Actuator For Sunroof C0 Actuator Control Module C1 Battery Control Module C2 Transmission Control Module C5 Thermal Sunroof C6 Datarer / Generator Control Module C5 Thermal Management C6 Datarer / Generator Control Module C6 Datarer / Generator Control Module C5 Thermal Management C6 D Laser Scanner C6 Drive Motor Control Module C6 Drive Motor Control Module <	×	-	-	-	-					
BF Sliding Door Rear Right Image: Constraint of the second se				-						
C0 Actuator For Exterior Noise • • • • • • * <				-						
C1 Battery Regulation • • • • • • *		•			•				_	
C2 Transmission Control Module 2 • • • • • • *		•			•			•		
C3 Drive Motor Control Module 3 • • • • • • *		•	•	-				•		
C4 DC/DC Converter Control Module••••••***C5 Thermal Management••••••••***C6 Battery Charger Control Module•••••••****C7 Pedestrian Protection•••••••**		•	•	_	•	•	•	•		
C5 Thermal Management••••••••••***C6 Battery Charger Control Module••••••••••** <td< td=""><td></td><td>•</td><td>•</td><td>-</td><td>•</td><td>•</td><td>•</td><td>•</td><td></td><td></td></td<>		•	•	-	•	•	•	•		
C6 Battery Charger Control ModuleImage: C		•	<u> </u>		•		•		_	
C7 Pedestrian Protection • • • • • • • * </td <td></td> <td>•</td> <td></td> <td>-</td> <td></td> <td></td> <td></td> <td></td> <td>_</td> <td></td>		•		-					_	
C8 Auxiliary Display Control Unit 2•••••••**		•	_	-						
C9 Rear MirrorImage: Constraint of the systemImage:		•		-	•					
CA Control Module For Sunroof••••••••***CB Rear Axle Steering•••••••••** </td <td></td> <td>•</td> <td></td> <td>-</td> <td>•</td> <td></td> <td></td> <td></td> <td></td> <td></td>		•		-	•					
CB Rear Axle SteeringImage: CB Rear Axle Steering <thimage: axle="" cb="" rear="" steering<="" th="">Ima</thimage:>					•				-	
CC Starter / Generator Control ModuleImage: Control ModuleImag					•					
CD Laser ScannerImage: CD Laser Scann	CB Rear Axle Steering				•			•		
CE Drive Motor Control Module 2 • • • • • • • • • • * *	CC Starter / Generator Control Module									
	CD Laser Scanner									
CF Control Unit Lane Change Assistant 2 🛛 🔍 🔍 🔍 🔍 🔍 🖉 🖉 🖉 🖉 🖉	CE Drive Motor Control Module 2								*	*
	CF Control Unit Lane Change Assistant 2	\bullet							*	*

A10 KAUPPA OY www.a10kauppa.fi

DO Front Axle Lift System								*	*
D1 Center Display			•	•				*	*
D2 Sliding Door Left			•	•				*	*
D3 Sliding Door Right				•				*	*
D4 Roll Control System 1				•				*	*
D5 Roll Control System 2				•				*	*
D6 Light Control Left 2				•				*	*
D7 Light Control Right 2		•	٠	•				*	*
D8 Projection Module in Left Matrix								*	*
Headlamp	•		•	•	•	•	-	×	*
D9 Projection Module in Right Matrix								*	*
Headlamp							•	*	*
DB Front Corner Radar 1								*	*
DC Front Corner Radar 2								*	*
DD Control Module 2 For Sunroof				•				*	*
DE Charger 1 Mobile Devices				•				*	*
DF Charger 2 Mobile Devices				•				*	*
EO Auxiliary Display Control Unit 1				•				*	*
EF Reference Control Unit				•			•	*	*

	SEAT DPF Func	tion List(Note:For reference only)						
NOTES:								
● This fu	nction is supporte	d. (Except that the electronic control unit not equipped)						
💥 This fu	nction may be supp	orted, which depends on the actual condition of the						
O This fu	nction is not supp	orted.						
▲ This fu	nction is the new	feature in this version.						
Vehicle	Year	DPF						
LEON	2000 - 2021							
		DPF Function List						
DPF Check	IDPF Check							
DPF Matchi	DPF Matching							
DPF Regene	eration							

SEA	T EPB Func	tion List(Note:For reference only)								
NOTES:	NOTES :									
• This function is supported. (Except that the electronic control unit not equipped)										
💥 This functi	* This function may be supported, which depends on the actual condition of the									
O This function is not supported.										
	▲ This function is the new feature in this version.									
Vehicle	Year	EPB								
Alhambra	2001 - 2021									
Altea	2004 - 2015									
Arona	2018 - 2021									
Arosa	2001 - 2004	\bullet								
Ateca	2017 - 2021	\bullet								
Cordoba	1999 - 2009	•								
Exeo	2009 - 2014									
Formentor	2021 -	\bullet								
Freetrack	2007 - 2015									
Ibiza	1999 - 2021									
Inca	2001 - 2003	•								
Leon	2000 - 2021									
Mii	2012 - 2021									
Tarraco	2019 - 2021	•								
Toledo	1999 - 2010	\bullet								
Toledo	Toledo 2013 - 2019 $lacksquare$									
EPB Function List										
Open Rear Brak	e Calipers(Rea	dy to change brake pads)								
		ter replacement of brake pads)								

SEA	AT ETC Func	tion List(Note:For reference only)							
NOTES :									
• This funct:	• This function is supported. (Except that the electronic control unit not equipped)								
	* This function may be supported, which depends on the actual condition of the								
O This funct:	O This function is not supported.								
▲ This funct:	ion is the new :	feature in this version.							
Vehicle	Year	ETC							
Alhambra	2001 - 2021								
Altea	2004 - 2015								
Arona	2018 - 2021	\bullet							
Arosa	2001 - 2004	•							
Ateca	2017 - 2021	\bullet							
Cordoba	1999 - 2009								
Exeo	2009 - 2014								
Formentor	2021 -	\bullet							
Freetrack	2007 - 2015								
Ibiza	1999 - 2021	•							
Inca	2001 - 2003	•							
Leon	2000 - 2021	•							
Mii	2012 - 2021	•							
Tarraco	2019 - 2021								
Toledo	1999 - 2010	•							
Toledo	Toledo 2013 - 2019								
ETC Function List									
Electronic th	rottle sensor r	eset							

SFAT Diagnostic Fun	ction List(Note:For reference only)									
NOTES:										
• This function is supported.										
= =	nich depends on the actual condition of the vehicle.									
○ This function is not supported.										
▲ This function is the new feature i										
Vehicle	Year									
Alhambra	2001 - 2019									
Altea	2004 - 2015									
Ateca	2017 - 2019									
Arosa Cordoba	2001 - 2004									
Exeo	<u> 1999 2009</u> 2009 2014									
Ibiza	1999 - 2019									
Inca	2001 - 2003									
Leon	2001 2003									
Mii	2012 - 2019									
Toledo	1999 - 2010									
Toledo	2013 - 2019									
Systemlist	EcuInfo Read Erase Live Actuation Basic . Codes Codes Data Test Setting Adaptatio									
01 Engine Control Module 1										
02 Transmission Control Module										
03 Brakes 1										
04 Steering Angle Sender										
05 Kessy										
06 Seat Adjustment Passenger Side										
07 Display Control Unit										
08 Air Conditioning										
09 Central Electrics	• • • • • • •									
OB Auxiliary Air Heater	$\bullet \bullet \bullet \bullet \bullet \bullet \circ \circ$									
OC Rear Axle Steering 2										
OD Sliding Door Left										
OE Media Player Position 1										
OF Radio Tuner - Digital										
10 Parking Assistance 2										
11 Engine Control Module 2										
12 Clutch Control Unit										
13 Adaptive Cruise Control										
14 Wheel Dampening Electronics										
15 Airbag										
16 Steering Column Electronics										
17 Dash Board										
18 Auxiliary Parking Heater										
19 Gateway										
1A Fuel Cell Engine	$\bullet \bullet \bullet \bullet \bullet \bullet \circ \circ$									
1B Active Steering	$\bullet \bullet \bullet \bullet \bullet \bullet \circ \circ$									
1C Vehicle Position Detection	$\bullet \bullet \bullet \bullet \bullet \bullet \circ \circ$									
1D Driver Identification	$\bullet \bullet \bullet \bullet \bullet \bullet \circ \circ$									
1E Media Player Position 2	$\bullet \bullet \bullet \bullet \bullet \bullet \circ \circ$									
20 High Beam Assistance	$\bullet \bullet \bullet \bullet \bullet \bullet \circ \circ$									
21 Battery Energy Control Module 2	$\bullet \bullet \bullet \bullet \bullet \bullet \circ \circ$									
22 All Wheel Control	$\bullet \bullet \bullet \bullet \bullet \bullet \circ \circ$									
23 Brake Boost	$\bullet \bullet \bullet \bullet \bullet \bullet \circ \circ$									
25 Immobilizer	$\bullet \bullet \bullet \bullet \bullet \bullet \circ \circ$									

		1				
26 Electronic Roof Control	•	•	•	•	• •	0
27 Display Control Unit Rear	•	•	•	•	• •	0
28 Climate Control Unit Rear	•	•		•	• 0	0
29 Light Control Left	•	•	•	•	• 0	0
2A Control Unit Wireless Charging	•	•		•	• 0	0
2B Steering Column Locking	•	•	•	•	• 0	0
2D Voice Amplifier	•	•		•	• 0	0
2E Media Player Position 3	•	•		•	• 0	0
30 Special Function 2	•	•		•	• 0	0
31 Engine Electronics Group	•	•		•	• 0	0
32 Lock Electronics	•	•	•	•	• 0	0
33 All OBD Systems	•	•		•	• 0	0
34 Ride Control System	•	•	•	•	• 0	0
35 Central Locking Control Module	•	•		•	• 0	0
36 Seat Adjustment Driver Side	•				• 0	0
37 Navigation	•				• 0	0
38 Roof Electronic Control Module	•	•		•	• 0	0
39 Light Control Right	•				• 0	0
3A Special Vehicle Assistant	•	•		•	• 0	0
3B Sensor Electronics	•	•		•	• 0	0
3C Lane Change Assistant	•			•	• 0	0
3D Special Function	•			•	• 0	0
3E Media Player Position 4	•	•		•	• 0	0
3F Dynamic Assembly Mounting	•	•		•	• 0	0
40 Air Conditioning Compressor	•	•		•	• 0	0
41 Diesel Pump Electronics	•	•	•	•	• 0	0
42 Door Electronics Driver Side	•	•		•	• 0	0
43 Bremskraftunterstutzung	•	•		•	• 0	0
44 Steering Assistance	•	•	•	•	• •	•
45 Interior Monitoring	•	•		•	• 0	0
46 Central Module Comfort System	•	•		•	• •	•
47 Sound System	•	•		•	• 0	0
48 Seat Adjustment Rear Driver Side	•	•	•	•	• 0	0
4A Rear Light	•	•		•	• 0	0
4B Multifunction Module	•	•		•	• 0	0
4C Tire Pressure Monitoring 2	•	•	•	•	• 0	0
4D Data Transfer Car2X_XXX	•	•	•	•	• 0	0
4E Control Head Rear Right	•	•	•	•	• 0	0
4F Central Electrics 2	•	•	•	•	• 0	0
50 Seat Adjustment 3rd Row	•	•	•	•	• 0	0
51 Drive Motor Control Module	•	•	•	•	• 0	0
52 Door Electronics Passenger Side	•	•		•	• 0	0
53 Parking Brake	•			•		•
54 Rear Spoiler	•	•	•	•	• 0	0
55 Headlight Regulation					• 0	0
56 Radio	•	•		•	• •	0
57 TV Tuner				•	• 0	0
58 Fuel Supply				•	• 0	0
5A Longitudinal Control				•	• 0	0
5B Seat Adjustment Rear Passenger Side	•			•	• 0	0
5C Lane Departure Warning System				•	• 0	0
5D Operation	•			•	• 0	0
5E Control Head Rear Left				•	• 0	0
5F Information Control Unit 1	•			•	• 0	0
			-	•	- 0	U

	1	1	1				·,
60 Tachograph	•		•	•	•	0	0
61 Battery Regulation	•	•	•	•	•	•	•
62 Door Electronics Rear Left	•		•	•	•	0	0
63 Entry Assistance Driver Side	•	•	•	•	•	0	0
64 Stabilizers	•	•	•	•	•	0	0
65 Tire Pressure Monitoring 1		•	•	•	•	0	0
66 Seat Adjustment Rear			•	•	•	0	0
67 Voice Control	•	•	•	•	•	0	0
68 Wiper Control Unit			•	•	•	0	0
69 Trailer Function	•	•	•	•	•	0	0
6A Door Automatic Rear Driver Side	•	•	•	●	•	0	0
6B Aerodynamics Control Unit	•	•	•	•	•	0	0
6C Camera System Rear View	•	•	•	•	•	0	0
6D Deck Lid Control Unit	•	•	•	•	•	0	0
6E Display Control Roof				●	•	0	0
6F Central Module Comfort System 2					•	0	0
71 Battery Charger					•	0	0
72 Door Electronics Rear Right			•	•	•	0	0
73 Entry Assistance Passenger Side		•	•	•	•	0	0
74 Chassis Control		•		•	•	0	0
75 Telematics Communication Unit	•			•	•	0	0
76 Parking Assistance	•	•		•	•	•	•
77 Telephone	•	•		•	•	0	0
78 Sliding Door Right	•	•	•	•	•	0	0
7A Door Automatic Rear Passenger Side		•		•	•	0	0
7D Auxiliary Heater		•		•	•	0	0
7E Dash Board Display Unit		•		•	•	0	0
7F Information Control Unit 2		•		•	•	0	0
80 Battery Regulation Auxiliary Accumulator		•		•	•	0	0
81 Gear Shift Control Module				•	•	0	0
82 Head Up Display		•		•	•	0	0
84 Night Vision				•	•	0	0
85 On-Board Camera				•	•	0	0
87 Lane Assist LT3	•	•		•	•	0	0
88 Multi Contour Seat Driver Side	•	•	•	•	•	0	0
89 Multi Contour Seat Passenger Side	•	•	•	•	•	0	0
8A Multi Contour Seat Rear Driver Side	•	•	•	•	•	0	0
8B Adaptive Cruise Control 2	•	•	•	•	•	0	0
8C Battery Energy Control Module	•	•	•	•	•	0	0
8D Multi Contour Seat Rear Passenger Side	•	•	•	•	•	0	0
8E Image Processing Electronics	•		•	•	•	0	0
8F Pretensioner Front Left	•	•	•	•	•	0	0
90 Pretensioner Front Right	•	•		•	•	0	0
91 Engine Control Module (ECM)	•	•	•	•	•	0	0
92 Transmission Electronics				•	•	0	0
93 Immobilizer						0	0
94 Airbag (SRS)	•	•	•	•	•	0	0
95 Electronic Stability Program			•	•		0	0
96 Instrument Cluster						0	0
97 Tachograph	•		•	•		0	0
97 Tachograph 98 Tire Pressure Monitoring	•		•	•		0	0
99 Electrical Ignition/starter Switch 9A Remote Control	•		•	•	•	0	0
			-	-			-
9B Driver's Door Electronics				•	•	0	0

9C A/C Electronics				\bullet	•	0	0
9D Auxiliary Heater (Fuel)				•	•	0	0
9E Auxiliary Heater (Electric)			•		•	0	0
9F Parking Heater, Water	•	•	•	•	•	0	0
AO Audio 5 Radio,		•	•	•	•	0	0
A1 Navigation		•		•	•	0	0
A2 CD Changer	•	•		•	•	0	0
A3 Telephone		•	•	•	•	0	0
A5 Front Sensors Driver Assistance System			•	•	•	0	0
A6 Microphone Control Unit	•	•	•	•	•	0	0
A7 Infotainment Interface	•		•	•	•	0	0
A8 External Communication Interface		•		•	•	0	0
A9 Actuator For Structure-Borne Sound		•		•	•	0	0
AA Wheel Brake Rear Right		•		•	•	0	0
AB Wheel Brake Rear Left				•	•	0	0
AC Reductant Control Module		•		•	•	0	0
AD Sensors Brake Systems	•	•	•	•	•	0	0
AE Telemetry Diagnostic Control Unit		•	•	•	•	0	0
BU Root Display/control Head (Root Control	•	•	•	•	•	0	0
B1 Upper Operating Field	•	•	•	•	•	0	0
B2 Parking Aid	•	•	•	•	•	0	0
B3 Trailer Function	•		•	•	•	0	0
B4 Vehicle Electrical System Control Module	•	•	•	•	•	0	0
B5 Programmable Special Module	•				•	0	0
B6 Steering Column Jacket Switch Module					•	0	0
B7 Access Startsystem Interface			•	•	•	0	0
B8 Electronic Roof Control 2					•	0	0
B9 Auxiliary Display Control Unit					•	0	0
BA Assembly Mounting			•	•	•	0	0
BB Door Electronics Rear Driver Side					•	0	0
					•	0	0
BC Door Electronics Rear Passenger Side					•	0	0
BD High Voltage Battery Charge Management			•	•	•	0	0
BE Sliding Door Rear Left					•	-	
BF Sliding Door Rear Right					•	0	0
CO Actuator For Exterior Noise	•		•	•	•	0	0
C1 Battery Regulation	•	•	•	•	•	0	0
C2 Transmission Control Module 2	•	•	•	•	•	0	0
C3 Drive Motor Control Module 3	•	•	•	•	•	0	0
C4 DC/DC Converter Control Module	•	•	•	•	•	0	0
C5 Thermal Management	•	•	•	•	•	0	0
C6 Battery Charger Control Module	•	•	•	•	•	0	0
C7 Pedestrian Protection	•	•	•	•	•	0	0
C8 Auxiliary Display Control Unit 2	•	•	•	•	•	0	0
C9 Rear Mirror	•	•	•	•	•	0	0
CA Control Module For Sunroof	•	•	•	•	•	0	0
CB Rear Axle Steering				•	•	0	0
CC Starter / Generator Control Module	•		•	•	•	0	0
CD Laser Scanner	•			•	•	0	0
CE Drive Motor Control Module 2	•			•	•	0	0
CF Control Unit Lane Change Assistant 2	•	•			•	0	0
DO Front Axle Lift System	•			•	•	0	0
D1 Center Display	•	•		•	●	0	0
D2 Sliding Door Left	•			•	•	0	0
D3 Sliding Door Right					•	0	0

A10 KAUPPA OY www.a10kauppa.fi

D4 Roll Control System 1	٠		•		•	0	0
D5 Roll Control System 2	•	•	•	•	•	0	0
D6 Light Control Left 2	•		•		•	0	0
D7 Light Control Right 2	•		•		•	0	0
D8 Projection Module in Left Matrix Headlamp	۲		•		•	0	0
D9 Projection Module in Kight Matrix	۲	•			•	0	0
DB Front Corner Radar 1	۲	•	•		•	0	0
DC Front Corner Radar 2	۲	•	•		•	0	0
DD Control Module 2 For Sunroof	۲	•	•		•	0	0
DE Charger 1 Mobile Devices	•		•		●	0	0
DF Charger 2 Mobile Devices	۲	•	•		•	0	0
EO Auxiliary Display Control Unit 1	•	•	•		•	0	0
EF Reference Control Unit	•	•	•		•	0	0

SEAT INJ Fur	nction List(Note:For reference only)				
NOTES:					
• This function is suppor	ted. (Except that the electronic control unit not equipped)				
X This function may be sup	pported, which depends on the actual condition of the				
O This function is not supported.					
▲ This function is the new feature in this version.					
Vehicle Year	INJ				
LEON 2000 - 2021					
INJ Function List					
Injector matching					

NOTES:		
	ction is supporte	d. (Except that the electronic control unit not equipped)
		orted, which depends on the actual condition of the
O This fun	ction is not supp	orted.
▲ This fun	ction is the new	feature in this version.
Vehicle	Year	LAP
Alhambra	2001 - 2021	*
Altea	2004 - 2015	*
Arosa	2001 - 2004	*
Cordoba	1999 - 2009	*
Exeo	2009 - 2014	*
Ibiza	1999 - 2021	*
Inca	2001 - 2003	*
Leon	2000 - 2021	*
Mii	2012 - 2021	*
Toledo	1999 - 2010	*
Toledo	2013 - 2019	*
		LAP Function List

SEA	T OIL Func	tion List(Note:For reference only)
NOTES:		
• This function	on is supported	d. (Except that the electronic control unit not equipped)
💥 This function	on may be suppo	orted, which depends on the actual condition of the
O This function	on is not supp	orted.
▲ This function	on is the new :	feature in this version.
Vehicle	Year	OIL
Alhambra	2001 - 2021	
Altea	2004 - 2015	
Arona	2018 - 2021	
Arosa	2001 - 2004	\bullet
Ateca	2017 - 2021	\bullet
Cordoba	1999 - 2009	
Exeo	2009 - 2014	•
1 01 mon 001	2021 -	•
Freetrack	2007 - 2015	•
Ibiza	1999 - 2021	•
Inca	2001 - 2003	•
	2000 - 2021	•
	2012 - 2021	•
	2019 - 2021	•
	1999 - 2010	
Toledo	2013 - 2019	
		OIL Function List
Adapting Vehic	le To Fixed In	terval
Adapting Vehic	le To Flexible	Service Interval

SEAT	SAS Funct	ion List (Note:For reference only)
NOTES:		
-	ion is supporte	d.(Except that the electronic control unit not equipped)
		orted, which depends on the actual condition of the
	ion is not supp	
▲ This funct:	ion is the new :	feature in this version.
Vehicle	Year	SAS
Alhambra	2001 - 2021	
Altea	2004 - 2015	
Arona	2018 - 2021	
Arosa	2001 - 2004	
Ateca	2017 - 2021	
Cordoba	1999 - 2009	
Exeo	2009 - 2014	
Formentor	2021 -	
Freetrack	2007 - 2015	
Ibiza	1999 - 2021	
Inca	2001 - 2003	*
Leon	2000 - 2021	
Mii	2012 - 2021	•
Tarraco	2019 - 2021	•
Toledo	1999 - 2010	•
Toledo	2013 - 2019	
		SAS Function List
Steering Angle	e Learning	

NOTES:		
• This fun	ction is supporte	d. (Except that the electronic control unit not equipped)
		orted, which depends on the actual condition of the
O This fun	ction is not supp	orted.
▲ This fun	ction is the new	feature in this version.
Vehicle	Year	SPS
Alhambra	2001 - 2021	*
Altea	2004 - 2015	*
Arosa	2001 - 2004	*
Cordoba	1999 - 2009	*
Exeo	2009 - 2014	*
Ibiza	1999 - 2021	*
Inca	2001 - 2003	*
Leon	2000 - 2021	*
Mii	2012 - 2021	*
Toledo	1999 - 2010	*
Toledo	2013 - 2019	*
		SPS Function List